





## 7UPTV Parental Control Lock

Your 7UPTV provides you with full parental control to restrict any unwanted viewing options.


Simply login to your 7UPTV player and click on "SETTINGS" icon from top right of your screen.




Scroll down in the settings menu to "PARENTAL CONTROL" and click on it.



A Parental Password window will appear. Simply enter your desired restricted password and click on Submit. Please remember this password for future access in future.



The Categories menu will appear and you can choose to restrict any number of categories by clicking on the lock icon. The locked categories will now be removed from your main menu Categories.



To "Un Lock" parental control, simply repeat the process by going to Settings, Parental and enter your Parental Password. Then click again on the locked category to unlock.

